






bruns

ECC 85 OA 910



GC100c GC100d 2 x OA 685
GC116c OA 721 4 x OA 685



Gezeichnete Schalterstellung: UKW-Taste gedrückt

● Arbeitskontakt
○ Ruhekontakt

Kontakt	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29
Netz																													
UKW	●	●			●			●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
KW	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
MW	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
LW	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
TA	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●

1/8W 1/4W 1/2W 1W 2W

Werkstoff	Datum	Name
Gezeichnet	4.67	Zscherer
Überprüft		
Maßstab	RCX 1001	